

### To Call the Warden







A tone is heard then warden speaks

Speak normally. You do not need to shout.

# **AMIE Radio Trigger**

Press to call warden



Light will show for five seconds

Copyright © Tunstall Group Ltd. 2000 Part Number: D9307005A1 Tel. 01977-661234 http://www.tunstall.co.uk/

## **Privacy**



If the button is pressed in the warden can hear you. If the button is out then the warden cannot hear you.

#### Privacy Override

If the warden calls and the Privacy button is out then the warden cannot hear you. To let the warden hear you just press the button on your AMIE radio trigger once.

If you make an alarm call, by pressing a button or pulling a cord, the warden will always be able to hear you.

When going This light away press this Away will come button. on.

Turnetali

When returning home press the Away button and the light will go off.



### Away facility (if fitted) | Door Entry System (if fitted)

You will hear a beep if someone rings your doorbell.



3 Press this button to open the door for the caller:



Press this button to speak to the caller. Release it to listen to the caller.



Press this button to stop unwanted calls for a few minutes.

