

Communicall Vi Quick Reference Card for DECT phone users

Answering an alarm call

- Answer the call (handset key) and listen to the full spoken alarm message. If necessary, make a note of the alarm details before selecting the alarm call
- Press * to speak to resident
- Press 0 to clear the speech module
- Press handset button to end call

NOTE: Failure to follow these steps fully and in order may result in the loss of important information about the source of the call.

Calling a resident

- Press handset key
- Call the number for Communicall
6060
- You will hear the message "enter resident number followed by star"
- Dial the speech module number followed by *
- You will be connected to the module
- Press 0 to clear the speech module
- Press handset button to end call

Communicall Vi Quick Reference Card for DECT phone users

Opening Doors

- Answer the call (handset key) and listen to the alarm message
 - Press * to speak to caller
 - Verify Identity of Caller
 - Press 7# to open door
 - Press 0 to clear the speech module
 - Press handset button to end call
-

Calling another handset

- Press the handset key
- Call the extrn. number for handset
- You will be connected to the desired handset
- Press handset button to end call

Calling external numbers

- Press the handset key
- Dial 9 to obtain external line
- Call the desired number
- Speak as normal
- Press handset button to end call