



Bogus Caller Button

What is it?

The bogus caller button is a small, discreet, MyAmie alarm trigger which has been pre-programmed with bogus caller functionality and allows the user to raise an alarm if they feel uncomfortable due to a visitor at their door.

Who is it for?

The bogus caller button is suitable for anyone of any age living independently who may need to raise an alarm to request assistance. The bogus caller button can offer peace of mind and an extra level of support. It can be particularly useful for older, infirm or disabled people, individuals who have recently been discharged from hospital or vulnerable people who could be at risk of crime or domestic abuse.

How does it work?

The bogus caller button should be located near the front or back door to allow an alarm call to be easily and discreetly placed to the monitoring centre.

When pressed, the bogus caller button activates a silent call for help to the monitoring centre. The operator can advise the user and listen to and record the call, escalating the situation if required and can provide evidence admissible in court.

Features

- Integrated alarm button with LED for visual reassurance that the alarm has been pressed
- An easy to fit wall mount
- Auto low battery monitoring and alerts

Benefits

- **Provides increased peace of mind and reassurance** for those living independently, their families and carers
- **Small, compact and easy to activate** improving safety levels
- **Enables maximum reliability** operating on the 869MHz dedicated social alarm frequency

The bogus caller package

The bogus caller button will be provided as a red button and a dark grey plastic surround. Included with the button is a wall mount, screw and a fixing to secure the bogus caller button in place within the wall mount.

Why Tunstall?

We focus on using the latest digital and mobile technology to enable people to feel safe, secure and independent, giving them the freedom to live the life they choose. Our products combine secure digital connectivity and mobile platforms.

We help you provide...

- **Intelligent, unobtrusive, person-centred care.**
- **Personalised, proactive and predictive services to improve quality of life.**
- **Integrated health, housing and social care.**

For more information please visit:

tunstall.co.uk

Specification

Technical

Dimensions:

26 x 36 x 14mm (W x H x D)

Weight:

7g

Radio frequency:

European 869 MHz social alarm frequency

Radio range:

Up to 75m indoors

Up to 750m line of sight

Waterproof:

IP67 (Up to 1m for 30mins)

Compatibility:

All Tunstall 869MHz alarm systems

Standards

EMC:

EN 55032, EN 301 489-1, EN 301 489-3, EN 50130-4

Safety:

EN 60950-1

Radio:

EN 300 220-2

Social alarm:

EN 50134-2

Design, manufacture, installation and service:

ISO 9001: 2015

Part number

Bogus caller button

P68005/90



Tunstall Healthcare (UK) Ltd is a member of the Tunstall Group.

Contact us on: **t: 01977 661234 | e: enquiries@tunstall.com | w: tunstall.co.uk | @TunstallHealth**

Our policy of continual development means that product specifications and appearance may change without notice. Tunstall does not accept any responsibility for any errors and omissions contained within this document. © 2020 Tunstall Group Ltd. Tunstall is a registered trademark. Tunstall Healthcare (UK) Ltd is a member of the Tunstall Group.

Version v10720