



Minuet Watch

What is it?

The Minuet Watch is a stylish, high-quality watch which incorporates a personal alarm, so that the wearer can trigger a call for help if they need it.

Who is it for?

The Minuet Watch is designed for anyone who would benefit from carrying a personal trigger at all times, including those with physical or age-related health conditions. It is useful for younger telecare users who prefer something more modern than the traditional personal pendant style alarm. Its discreet, contemporary design makes it ideal for situations where a personal alarm needs to be more covert, such as with vulnerable people or where there is a risk of domestic violence.

How does it work?

Used in the same way as a standard personal trigger, when the user requires assistance all they need to do is press the alarm button on the watch face. The Minuet Watch will then send a radio signal to the Lifeline home unit or other Tunstall compatible telecare system, which then raises a call to the monitoring centre.

The Minuet can be worn as a watch around the wrist using the supplied wrist strap or around the neck using the supplied neck cord and holder.

Features

- High quality, Swiss designed watch with ultra-reliable, integrated alarm operation
- Lightweight, stylish and comfortable to wear
- Different wearing options to swap the watch face between the wrist strap and the neck cord
- LED indication identifies if the alarm button has been pressed or if the battery is low
- Auto low battery reporting to the monitoring centre
- Waterproof to IP67 standard

Benefits

- **Provides increased peace of mind and reassurance** for those living independently, their families and carers
- **Modern, stylish and discreet design** increases regular wear, provides additional protection levels and improved safety
- **Versatile and flexible for personalisation** with a wide range of straps available from high street retailers
- **Compatible** with Tunstall Lifeline Smart Hub, Vi/Vi+/Connect/Connect+/400/4000+ home units and other Tunstall telecare enabled systems

The Minuet Watch package

The Minuet Watch comes as a single watch face with a standard size wrist strap and neck cord. Optional extras are available separately.

Why Tunstall?

We focus on using the latest digital and mobile technology to enable people to feel safe, secure and independent, giving them the freedom to live the life they choose. Our products combine secure digital connectivity and mobile platforms.

We help you provide...

- **Intelligent, unobtrusive, person-centred care.**
- **Personalised, proactive and predictive services to improve quality of life.**
- **Integrated health, housing and social care.**

For more information please visit:

uk.tunstall.com



Specification

Technical

Dimensions:

46 x 38 x 13 mm (L x W x D)

Watch strap size:

18mm (standard size)

Weight:

24g

Radio frequency:

European 869 MHz social alarm frequency

Radio range:

Up to 50m (in building), 200m (line of sight)

Battery type:

Radio Transmitter: CR2032

Battery life:

Watch: 5 years (non replaceable)

Radio Transmitter: 3 years (replaceable)

Operating temperature:

-10°C to +55°C

Watch accuracy

-10/+20 sec / month (at 25°C)

Standards

Approval:

EN 50134-2

CE:

Compliant

Waterproof:

IP67

Social alarm:

EN 50134-2 (trigger device)

Design, manufacture, installation and service:

ISO 9001: 2008

Part numbers

Minuet Watch

67005/21

Tunstall Healthcare (UK) Ltd is a member of the Tunstall Group.

Contact us on: **t: 01977 661234** | **e: enquiries@tunstall.com** | **w: uk.tunstall.com** | **@TunstallHealth**

Our policy of continual development means that product specifications and appearance may change without notice. Tunstall does not accept any responsibility for any errors and omissions contained within this document. © 2018 Tunstall Group Ltd. Tunstall is a registered trademark. Tunstall Healthcare (UK) Ltd is a member of the Tunstall Group.

Version v10318